


## How to retrieve the password of an NVR/DVR via QR Code Verification

1. Run the device and go to the login interface. Click the 'Forgot password' option.



2. A QR code will be displayed. Send the value or a photo of this QR code to technical support. You will receive a temporary password valid for the current day.

